



World Control Panel

Written By: Steve Lodefink



TOOLS:

- [CNC cutter \(1\)](#)
(optional) I wish I'd used one for all the drilling!
- [Center punch \(1\)](#)
with a sharp tip
- [Computer and inkjet printer \(1\)](#)
- [Drill and bits \(1\)](#)
1/6", 1/8", 13/64", 11/32", 10mm You'll also need bits to match your toggles and buttons; ours were about 1/4" and 9/32".
- [File or belt sander \(1\)](#)
to deburr and round aluminum edges
- [Hammer \(1\)](#)
- [Hot glue gun \(1\)](#)
- [Router with rabbeting bit \(1\)](#)
(optional)
- [Rubber Mallet \(1\)](#)
(optional) to flatten the aluminum if you bend it
- [Sander, random orbit \(1\)](#)



PARTS:

- [Switches, toggle, panel mount \(7\)](#)
- [Switches, momentary, panel mount \(1\)](#)
medium (2), any size (1) for sound buttons and the Larson Scanner mode button
- [EMS Larson Scanner Kit from evilmadscience.com. \(1\)](#)
Get the one with the 10mm diffused LEDs.
- [Digital recording module \(1\)](#)
9V RadioShack #276-1323, radioshack.com
- [LEDs, 3mm, diffused \(1\)](#)
blue (25), red (10), amber (10)
- [LEDs, 5mm \(1\)](#)
green (4), red (2) for switch indicators
- [LED, 5mm, flashing \(2\)](#)
the kind with the integrated flasher
- [Resistors, various values \(62\)](#)
All LEDs in this project need current-limiting resistors. Typical values for

- [Sandpaper, 50 and 180 grits \(1\)](#)
- [Screwdriver, Phillips head \(1\)](#)
- [Soldering iron and solder \(1\)](#)
- [Spray-mount adhesive \(1\)](#)
- [Table saw or miter saw \(1\)](#)
- [Wire cutters and strippers \(1\)](#)

Limiting resistors: Typical values for different colored LEDs running at 4.5V are: red 180Ω, blue 68Ω, white 68Ω, green 120Ω, and amber 150Ω. But be sure to use resistors that are appropriate for the actual LEDs that you use.

- [Cable ties, small \(7\)](#)
- [Heat-shrink tubing \(1\)](#)
(optional)
- [IC, 555 timer \(1\)](#)
- [Transistor, PNP, 2907 type \(1\)](#)
- [Resistors: 4.7kΩ \(1\), 150kΩ \(1\) \(1\)](#)
- [Capacitor, electrolytic, 1 F \(1\)](#)
- [Capacitor, ceramic, 0.1mF \(1\)](#)
- [LEDs, high brightness \(1\)](#)
white (7), wide angle: red (3)
- [Perf board, about 2"×3" \(1\)](#)
- [Hardwood lumber \(1\)](#)
1"×4", 26" total length
- [Aluminum sheet \(1\)](#)
1"×14 1/2"×10 1/2"
- [Plywood \(1\)](#)
1"×11"×15 1/2"
- [Diffusion paper or gels \(1\)](#)
such as amazon.com #B000265DJU
- [Testors decal paper, clear \(1\)](#)
- [Acrylic sealant, clear \(1\)](#)
- [Wood screws, small \(8\)](#)
- [Wood glue \(1\)](#)
- [Battery holder, 3 x AA \(1\)](#)
- [Hookup wire \(1\)](#)

SUMMARY

Zoinks!

This video can't be played with your current settings.
Please switch to a browser that provides native H.264 video support or
install [Adobe Flash Player](#).

My son Harlan and his pals love to play “Agents.” When he asked me if I could build him a control panel that had “a bunch of switches and random blinking lights,” I couldn’t have been happier.

I have to admit, I have a bit of a control panel fetish, and my favorite thing about electronics tinkering is making lights blink — which is just about all this device really does.

I immediately imagined some kind of backlit, brushed-metal map of the world, with a radar scanner and a variety of indicator lights and toggle switches that would allow him to communicate with field agents, remotely dispatch weaponized sharks, or detect enemy activity.

The console employs a combination of readymade and custom circuits to achieve various lighting and sound effects. Ours is used for world domination, but the same basic panel would work equally well for tracking the migration of a swarm of Monarch butterflies, or detecting unicorns, if that’s what you need. Here’s how I built it.

Step 1 — Design the panel.




- I had a solid idea of how the perforated map display might work, but I wasn't sure how to achieve my vague "radar scanner" concept.
- Then I remembered that Evil Mad Science (where else would you buy parts for a world domination panel?) sells a kit to build a Larson Scanner — you know, that light-chaser effect made famous in the Knight Rider and Battlestar Galactica TV shows. It's perfect for "scanning the world" before flipping the various function switches.
- I also ordered amber, blue, and red 3mm diffused LEDs from EMS.
- RadioShack's digital sound-recording module sells for \$10 and uses nonvolatile memory, so your last recorded sound isn't lost when the power goes away. I added one of these to the panel to serve as a "field communicator."
- In keeping with the 1960s sci-fi/spy motif I had in mind, I decided to control everything with a bank of classic metal toggle switches and indicator lights.

Step 2 — Build the cabinet.




- You can use a pre-built enclosure, or build your own. Here's how I made mine, angled toward the operator like an old studio mixer.
- For the left and right sides, cut an 11" length of 1"×4" hardwood lumber in half diagonally, creating 2 pieces, each 1" high at one end and 3" at the other. For the front and rear sides, cut a 15" length straight across to leave a 1" wide piece for the front, and a 3" piece for the rear.
- Miter all 4 sidepieces to 45°, then clamp and glue them like a picture frame. Once the glue has dried, sand the joints flush. (I had to add screws later because glue wouldn't stick to the oily ipê wood that I used — don't use ipê!)
- Cut a bottom panel 11"×15-1/2" from 1/8" plywood and attach it with 4 wood screws.
- The top panel is a 14-1/2"×10" piece of 1/8" aluminum sheet. I used a router to cut a 1/8"-deep rabbet in the topside of the wooden frame, to allow the top panel to sit flush. Then I rounded the corners of the aluminum with a 50-grit sanding block to match the radius of the rabbeting bit.

Step 3 — Prepare the panel.



- Figure out exactly where you want all your controls and displays to go. Once you're satisfied with your layout, mark everything for drilling with a scribe or punch.
- I found a "pixel map" of the world online, and scaled it to a size that worked well with my panel dimensions. I printed it out as a template and glued it to the panel with spray mount. Then I used a center punch and hammer to mark each "pixel" for drilling.
- Since I would be inserting 3mm LEDs through some of the map holes, I drilled them with a 1/8" bit, which is a little over 3mm.
- Then I drilled holes for the Larson Scanner, the sound recorder's speaker grill and mic, the toggle switches and 5mm indicator LEDs, and the buttons that operate the sound recorder and Larson Scanner. You can download my [drilling template](#).
- Finally, I drilled 4 small holes near the corners, for screws to secure the panel.

Step 4 — Prepare the panel. (Continued)




- Once all the drilling was done, I pounded the panel flat with a rubber mallet, and used a random-orbit sander to deburr all the holes at once and clean up the panel.
- To give the aluminum a nice “brushed” look, I hand sanded it with 180 grit in long, even, horizontal strokes.
- Since I was planning to use backlighting effects for the map display, I glued a sheet of photographic diffusion paper to the backside of the map, to act as a rear projection screen. You can just poke holes in the diffusion paper wherever you want to install an LED.
- Finally, I printed some free web UI icons (“Brightmix” icons, from <http://opengameart.org>) on a sheet of clear Testors decal paper and applied the appropriate icon above each toggle switch hole. These decals need to be sealed with clear acrylic before use.

Step 5 — Install toggles and batteries.




- Install the toggle switches and indicator lights into their mounting holes. I cinched small zip ties around the base of each indicator LED as spacers so they sit near-flush with the panel. Wire it up so that the main power switch feeds power to the rest of the switches, and each switch powers its own indicator LED.
- Power is supplied by a 3×AA battery box mounted to the back panel. Use alligator clips to temporarily connect it to the main power switch. You'll connect and disconnect it many times during assembly and troubleshooting.

Step 6 — Build the “red alert” flasher circuit.



- I wanted a flashing backlight effect to indicate a “global red alert” situation. To achieve the flash, I turned to the good old 555 timer IC.
- I found a simple 555 flasher circuit on the web and built it onto a small piece of perf board. I used the 555’s output to flash 7 white LEDs through a single PNP transistor. I also added 3 bright red 10mm LEDs (these don’t flash) to the board. Follow the schematic to build the board.
- Leave the LED leads long so you can bend them to direct the light to different areas of the map. Mount the flasher board to the bottom panel with hot glue so it can project its light onto the back of the map. The switch indicator lamp for the “red alert” function is a 5mm red flashing LED.

Step 7 — Add the map LEDs.



- Four of the toggle switches control clusters of different colored LEDs — in my case, blue for major cities, red for Atlantic coastal areas, amber for “Eastern locations,” and a single blue LED for Seattle, our home base.
- I also wired a red flashing LED behind the panel parallel with the Seattle LED, to illuminate the surrounding holes with a flashing “home base” effect. These functions feature green power indicator LEDs above their switches. All of the LEDs in this project require appropriate current-limiting resistors.
- To wire the through-hole map lights, I first harvested some twisted-pair wiring from an old network cable I found in the trash. The wire inside these cables is conveniently color-coded and pre-bundled into pairs — great for hand-wiring small electronics projects.
- Solder a current-limiting resistor and a length of colored wire pair to each 3mm LED, and then insert the LEDs into the map holes from behind, securing each with a dab of glue.
- Then gather up the similarly colored LED wires and solder the anode wires to their respective power switches, and the cathode wires to ground.

Step 8 — Install scanner and sound.



- The Larson Scanner is configured to run on 3V power. Since the World Control Panel operates on 4.5V, you'll have to replace the kit's current-limiting resistors with new 120Ω resistors.
- The scanner PCB also has a momentary switch that controls its speed and brightness; I replaced it with a panel-mount button.
- Install the sound module by hot-gluing both the speaker and the PCB to the backside of the top panel. I replaced the onboard buttons for recording and playback with a pair of red and black panel-mount momentary buttons. Although the datasheet for the module specifies 9V power, mine worked fine with 4.5V.
- Finally, solder the wires to the battery box, and secure the panel with 4 wood screws.

Step 9 — Take It Further



- The World Control Panel is really just a fun box of switches and lights, but the platform begs for further development. Imagine adding USB, wireless data, microcontrollers, BlinkM smart LEDs, and other technology to improve the fun — or to really start monitoring and controlling your global concerns.
- Let us know what you do with yours in the comments.

This project first appeared in [MAKE Volume 32](#), page 134.

This document was last generated on 2012-12-02 11:06:55 PM.